

ANALOG WAY
 LIVECORE™ – Crestron 2-series & 3-series
 MODULE FRAME/LOGO

CONTACT SUPPORT

COMPANY NAME:	ANALOG WAY
SUPPORT CONTACT:	-
EMAIL ADDRESS:	techsupport@analogway.com (Europe, Middle East and Africa) techsupport@analogwayusa.com (Americas) techsupport@analogwayasia.com (Asia Pacific)
PHONE:	+33 1 81 89 08 76 (Europe, Middle East and Africa) +1 212 269 1902 (Americas) +65 6292 5800 (Asia Pacific)
ADDRESS:	Analog Way SAS 2/4 rue Georges Besse 92160 Antony - France
NOTES:	Driver version V3.01, compatible with LiveCore™ Firmware v4.00.x or above
HAND-IN DATE:	January 3, 2017

GENERAL INFORMATION

SIMPLWINDOWS NAME:	Livecore_frame_logo_V3.01
CATEGORY:	Logic
VERSION:	Driver version V3.01
SUMMARY:	This is an optional module for controlling LiveCore™ series processors. It mainly provides misc. information related to Frames and Logos.
GENERAL NOTES:	
CRESTRON HARDWARE REQUIRED:	3-series processor
SETUP OF CRESTRON HARDWARE:	
VENDOR FIRMWARE:	LiveCore™ firmware v4.00.x or above
VENDOR SETUP:	
CABLE DIAGRAM:	TCP-IP

ANALOG WAY
 LIVECORE™ – Crestron 2-series & 3-series
 MODULE FRAME/LOGO

CONTROL: Inter_connect_Modules

From_Module_Main	S	To be connected to the main module (LiveCore_Main)
Refresh_All	D	Pulse for module initialization

CONTROL: Chek_Frame - X is the frame index (1=>8)

Check_FrameX_Infos_PB	D	Pulse to update Frame X status
-----------------------	---	--------------------------------

CONTROL: Check_logo - X is the logo index (1=>8)

Check_LogoX_Infos_PB	D	Pulse to update Logo X status
----------------------	---	-------------------------------

ANALOG WAY
 LIVECORE™ – Crestron 2-series & 3-series
 MODULE FRAME/LOGO

FEEDBACK: Inter_connect_Modules

To_Module_Main	S	To be connected to the main module (LiveCore_Main)
Message_Txt	S	Status message to be displayed in user interface. To be connected to the main module (LiveCore_Main)
Refresh_In_Progress_FB	D	Module initialization in progress
Next_Module_Refresh_OS	D	To be connected to the next module for daisy chain initialization

FEEDBACK: Frame - X is the frame index (1=>8)

FrameX_Valid_FB	D	Frame X validity
FrameX_Used_In_One_Program_FB	D	1 if frame X is used in one screen Program or more
FrameX_Used_In_One_Preview_FB	D	1 if frame X is used in one screen Preview or more
FrameX_Width_FB	A	Frame X width (pixel)
FrameX_Height_FB	A	Frame X width (pixel)
FrameX_Name_FB	S	Frame X label (16 char. Max)

FEEDBACK: Logo - X is the logo index (1=>8)

LogoX_Valid_FB	D	Logo X validity
LogoX_Used_In_One_Program_FB	D	1 if Logo X is used in one screen Program or more
LogoX_Used_In_One_Preview_FB	D	1 if Logo X is used in one screen Preview or more
LogoX_Width_FB	A	Logo X width (pixel)
LogoX_Height_FB	A	Logo X width (pixel)
LogoX_Name_FB	S	Logo X label (16 char. Max)